






Standard Presser Foot

Sew straight stitches and zigzag stitches on lightweight and heavyweight materials.




Overcasting Presser Foot

Prevent cut edges of fabric from fraying and shrinkage by aligning the edge with the guide.



Rolled Hemming Presser Foot

Create hems by sewing the edge of fabric while folding it twice to a narrow width of about 1/8".




Hemming Presser Foot for Zigzag

Create hems by sewing the edge of fabric with a zigzag stitch while folding the fabric twice to a narrow width of about 1/8".




Buttonhole Presser Foot

Automatically sew buttonholes by simply placing the button in the holder.



Decorative Stitch Presser Foot

Sew satin stitches, decorative stitches, and letters with this presser foot. Also, accurately sew buttonholes near thick seams that are hard to reach.



Straight Stitch Presser Foot

Since the needle drops into a small round opening, the seam is stabilized to create perfect straight stitches.




Binder Presser Foot

Used for folding bias tape in four while edging fabric at a width of about 0.2". Single fold tape with a width of about 0.4" to 0.5" can also be used.



Button Attaching Presser Foot

Hold a button in place and attach it using the zigzag stitch.



Zipper Presser Foot

Closely sew along the edges of a zipper. You can attach this presser foot on either side of the needle (left or right) depending on which side of the zipper is being sewn.



Walking Foot

Sew stretch fabrics (knits), hard-to-feed materials (vinyl or leather), and unevenly fed material (quilts) with ease.



Patchwork Presser Foot

Accurately piece together patchwork with a seam allowance of 1/4" or 1/8".



Invisible Zipper Foot

Insert concealed zippers with this presser foot.




Blind Stitch Presser Foot

Sew blind hem stitches along the hems of pants and skirts to be invisible from the right side of the fabric.



1/4" or 7 mm Guide Foot

Piece together patchwork with a seam allowance of 1/4" (6.5 mm) or 7 mm. Available in 1/4" and 7 mm.



Gathering Foot

Create gathers in one or two pieces of fabric by changing the stitch length, thread tension, and presser foot pressure.



Smooth Presser Foot

Made of fluorocarbon resin, this presser foot smoothly feeds vinyl, leather, and other hard to feed materials.



Roller Foot

Smoothly feed vinyl, leather, and other hard to feed materials. The rollers at the front and back prevent materials from sticking or bunching up making perfect seams.



Presser Foot with Guide

The marks at a 0.07" spacing on this presser foot can be used as a guide for stitching parallel straight or decorative stitching.



Edge Sewing Presser Foot

Stitch seam lines, such as stitch in the ditch on patchwork quilts or conceal seams on clothes with this presser foot.




Quilt Presser Foot (For Ruler)

Used for free motion quilting using a ruler. The front of the presser foot is lowered making it easier to see the needle area.



Quilt Presser Foot

Used for free motion quilting. Adjust the height of the presser foot according to the thickness of the fabric.



Quilt Presser Foot (Open Type)

Opened at the front, this presser foot allows for easy visibility at the needle area when free motion quilting.



Quilt Presser Foot (Zigzag Type)

Used for free motion quilting with zigzag stitches.



Open Toe Presser Foot

The wide opening at the front of this presser foot makes applique and other designs easy to see, which is useful for curvy decorative stitching.




Applique Presser Foot

Since the front and back of this presser foot are short and transparent, appliques and other designs are easy to see.



Pearl Attaching Presser Foot

Add strands of pearls or beads to any project by passing the pearls or beads through the dome-shaped groove in the middle of the presser foot.



Cording Presser Foot (for 3 Cords)

Create three-dimensional decorations on any project by adding up to three thin decorative cords or embroidery thread.



Cording and Embroidery Presser Foot

Add cording and other embellishments to your quilt with this presser foot.



Advanced Quilter's Kit

This set contains the following: Edge Sewing, Quilt (Open Type), Quilt (Zigzag Type), Open Toe, Applique, and Pearl Attaching Presser Foot



Heavy User Kit


This set includes the following: Presser Foot with Guide, Button Attaching, Invisible Zipper, Rolled Hemming, Cording and Embroidery, and Binder Presser Foot.



Creative Set


This set contains the following: Presser Foot with Guide, Applique, Cording and Embroidery, Pearl Attaching, Cording (for 3 Cords), Open Toe Presser Foot, and 5 bobbins.

SEMI-PROFESSIONAL SEWING MACHINE PRESSER FEET



Standard Presser Foot

This basic presser foot is easy to use in various sewing applications, such as straight lines or curves on medium to heavyweight materials.



Zipper Attaching Foot

The position of this presser foot can be switched between the left and right side of the needle allowing for perfect alignment to attach zippers.



Solid Cording Foot (Right)

This one-sided presser foot presses down on only one side of the fabric and is useful for sewing along edges of zippers or piping.



Solid Cording Foot (Left)

This one-sided presser foot presses down on only one side of the fabric and is useful for sewing along edges of zippers or piping.




Compensating Foot (Left 1.5 mm)

Used for stabilizing stitching 0.06" (1.5 mm) to the right of a thick seam. It is useful for coverstitching.




Compensating Foot (Right 1.5 mm)

Used for stabilizing stitching 0.06" (1.5 mm) to the left of a thick seam. It is useful for coverstitching.



**Compensating Foot
(Right 1/4" or 7 mm)**

Used for stabilizing stitching 1/4" (6.5 mm) or 7 mm to the left of a thick seam. Available in 1/4" and 7 mm.



**Invisible Zipper Foot
(Metal)**

This presser foot is made of highly durable metal to insert a concealed zipper.



**Invisible Zipper Foot
(Plastic)**

This presser foot is made of common plastic to insert a concealed zipper.




Hinged Zipper Foot

This narrow hinged presser foot is useful for sewing zippers and narrow pieces.



**Regular Hinged
Foot (1/4" or 7mm)**

Piece together patchwork with a seam allowance of 1/4" (6.5 mm) or 7 mm. Available in 1/4" and 7 mm.



Smooth Foot

Made of fluorocarbon resin, this foot allows you to smoothly and easily sew hard to feed materials such as vinyl or leather.



**1/4" or 7 mm
Presser Foot**

Accurately piece together patchwork with a seam allowance of 1/4" (6.5 mm) or 7 mm. Available in 1/4" and 7 mm.



Hinged Cording Foot

One-sided presser foot presses down only on one side of the fabric. Useful for sewing along edges of zippers and piping. It allows thick seams to easily be crossed.



1/5" Quilting Foot

Free motion quilt with a 1/5" distance from the needle entry point to the outer edge of the presser foot.



1/4" Quilting Foot

Free motion quilt with a 1/4" distance from the needle entry point to the outer edge of the presser foot.




**Quilting Foot Front
Open Toe**

This presser foot for free-motion sewing is open at the front so that the needle area is easy to see.



**Quilting Foot Side
Open Toe**

This presser foot for free-motion sewing is open at the side so that the needle area is easy to see.




**1/4" Quilting Foot
(For Ruler)**

With a distance of 1/4" from the needle entry point to the outer edge of the presser foot, sew using a ruler as a guide.



Echo Quilting Foot

This presser foot for free motion quilting has circular guidelines at 1/4" and 5/8" useful for echo quilting.



Hemming Foot

Sew the edge of fabric while folding it twice to a narrow width. Additional, it is used for finishing ruffles and handkerchief edges.




Piping Foot

Used to sew the edge of the fabrics along with the right side of the piping.




Even Feed Foot

Sew stretch fabrics (knits), hard-to-feed materials (vinyl and leather), and unevenly fed material (quilts) with ease.



**Quilt Guide for Even
Feed Foot**

This guide is used for sewing parallel rows of stitching that are equally spaced.




Foot for Thin Fabric

Designed specifically to sew lightweight materials.



**Professional
Attachment Set**

This set contains the following: Swing Gauge, Hinged Zipper Foot, Smooth Foot, and Piping Foot.



Standard Presser Foot

This basic presser foot is easy to use in various sewing applications, such as straight lines or curves on medium to heavyweight materials.



Hinged Zipper Foot

This narrow hinged presser foot is useful for sewing zippers and narrow pieces.




Invisible Zipper Foot (Metal)

Made from highly durable metal, this presser foot is used for inserting a concealed zipper.



Smooth Foot

Made of fluorocarbon resin, this foot allows you to smoothly and easily sew hard to feed materials such as vinyl or leather.




Regular Hinged Foot (1/4" or 7 mm)

Piece together patchwork with a seam allowance of 1/4" (6.5 mm). Available in 1/4" and 7 mm.



1/4" or 7 mm Presser Foot

Accurately piece together patchwork with a seam allowance of 1/4" (6.5 mm) or 7 mm. Available in 1/4" and 7 mm.




Compensating Foot (Right 1/4" or 7 mm)

Used for stabilizing stitching 1/4" (6.5 mm) or 7 mm to the left of a thick seam. Available in 1/4" and 7 mm.



Quilting Foot

Used for free motion sewing and ruler work.



Echo Quilting Foot

This presser foot for free motion quilting has circular guidelines at 1/4" and 5/8" useful for echo quilting.



Professional Attachment Set

This set contains the following: Swing Gauge, Hinged Zipper Foot, Smooth Foot, and Piping Foot.



Quilting Foot

Free motion presser foot used for free motion quilting and ruler work.



Couching Foot

Used for sewing decorative thread, yarn, and much more to give your quilt a three-dimensional feel.



Open Toe Foot

Used for free motion quilting, this presser foot is open at the front so that the needle area is easy to see.



Glide Foot


Shaped like a bowl, this foot is intended to be used for quilting when gliding along applique and other slightly three-dimensional embellishment.

EMBROIDERY MACHINE FRAMES




Pocket Frame

Embroider beautiful designs on sleeves, pockets, cap side parts, and much more.



Magnetic Frame

Embroider designs on bags, pouches, apparel, and more. Three available sizes: small (40 mm x 50 mm), medium (40 mm x 60 mm), and large (80 mm x 100 mm).




Sock & Wristband Frame

Embroider designs on socks and wristbands.



Mounting Base with Sock Gauge

Mounting base for sock gauge to embroider socks and wristbands.



TFA Frame


Embroider designs on t-shirts, sweatshirts, and other garments. Three available sizes: small (50 mm), medium (110 mm), and large (138 mm).



Shoe Frame


Embroider designs on shoes.

OVERLOCK SEWING MACHINE PRESSER FEET



Standard Presser Foot

Used to regular overlock stitching. It can also be used for sewing tape while overlocking the edge of the fabric.



Blind Stitch Presser Foot (For Right Needle)

Sew blind hem while overlocking the edge of the fabric.




Regular Hinged Foot (1/4" or 7mm)

Piece together patchwork with a seam allowance of 1/4" (6.5mm).




Elasticator Presser Foot

Sew in elastic tape while overlocking the edge of the fabric.




Cording Presser Foot

Used for sewing nylon thread or wire for crafts.




Beading Presser Foot

Sew on strands of pearls, beads, or sequins. The strand can also be sewn in the middle of fabric by sewing along a folded edge with flatlock.




Curved Beading Presser Foot

Sew strands of pearls, beads, or sequins along curves.




Piping Presser Foot

Sew piping while overlocking the edge of the fabric.



Gathering Presser Foot

Used for sewing together two pieces of fabric while creating gathers. Gathers can also be created in single piece of fabric.



Chain Stitch Presser Foot

Designed specifically for sewing chain stitches on a coverstitch machine.



PRESSER FOOT PART NUMBERS

	HZL-NX Series	DX-3000QVP	HZL-DX Series	HZL-F Series (Exceed)	HZL-G Series	HZL-H Series	HZL-L Series	HZL-350Z Series
Standard Presser Foot	40197188			40057923		40165250	40169908	40151600
Overcasting Presser Foot		40080960			40110163	40145869	40169900	40145869
Buttonhole Presser Foot		40080966			40110162	40165251	40169879	40151623
Decorative Stitch Presser Foot	40110165		40112905	A9823-008-0A0	40112905	40145868	40169901	40145868
Button Attaching Presser Foot			40080969			40151630	-	40151630
Zipper Presser Foot			A9823-010-0A0			40151622	40169903	40151622
Invisible Zipper Foot			40080955				-	
Blind Stitch Presser Foot	40110164		40112904	40080961	40112904	40145872	40169902	40145872
Smooth Presser Foot			40079312				-	
Roller Foot			40117711				-	40117711
Rolled Hemming Presser Foot			40080958			40145870	-	40145870
Hemming Presser Foot for Zigzag			40080957				-	
Straight Stitch Presser Foot	40145874			-		40145874	-	40145874
Binder Presser Foot			400800954				-	
Walking Foot	-			40080963		40145876	40169917	40145876
Patchwork Presser Foot	40197827			40080959			-	
1/4" Guide Foot	40197829			40164071			-	
7mm Guide Foot	40197832				-			
Presser Foot with Guide			40080952				-	
Edge Sewing Presser Foot			40080965				-	
Quilt Presser Foot (For Ruler)	40197266			40201927			-	
Quilt Presser Foot	40224352*			40177011			-	
Quilt Presser Foot (Open Type)	40177014*			40080949			-	
Quilt Presser Foot (Zigzag Type)	40080953*			40080953		40145873	40169916	40145873
Open Toe Presser Foot			40080962				-	
Applique Presser Foot			40080951				-	
Pearl Attaching Presser Foot			40080956				-	
Cording & Embroidery Presser Foot	40224357			40080950			-	
Cording Presser Foot (for 3 Cords)			A9829-880-0A0			40145871	-	40145871
Gathering Foot	40165262*			40165262			-	40145875
Adapter Shank	40207583							
Quilt Guide	40190227			A9833-550-0A0		40151624	40169918	40151624

*Always use adapter shank (40207583)

	TL Series
Standard Presser Foot	A9836-D25-0A0
Zipper Attaching Foot	A9838-090-0A0
Solid Cording Foot (Right)	A9844-D25-AA0
Solid Cording Foot (Left)	A9844-D25-BA0
Hinged Cording Foot	A9844-D25-CA0
Invisible Zipper Foot (Metal)	A9841-D25-AA0
Invisible Zipper Foot (Plastic)	A9841-D25-BA0
Smooth Foot	A9840-D25-0A0
Hemming Foot	A9837-090-0A0
Piping Foot	A9845-D25-0A0
Compensating Foot (Right 1.5mm)	A9843-D25-AA0
Compensating Foot (Left 1.5mm)	A9843-D25-BA0
Compensating Foot (Right 1/4")	A5149-E98-ZA0
Compensating Foot (Right 7mm)	A9850-D25-0A0
Regular Hinged Foot (1/4")	40171426
Regular Hinged Foot (7mm)	40171430
1/4" Presser Foot	40171428
7mm Presser Foot	40171432
Even Feed Foot	A9811-D25-0A0
1/5" Quilting Foot	A9811-E98-AA0A
1/4" Quilting Foot	A9811-E98-BA0A
Quilting Foot Front Open Toe	40171422
Quilting Foot Side Open Toe	40166734
1/4" Quilting Foot (For Ruler)	40166729
Echo Quilting Foot	40166739
Foot for Thin Fabric	A9813-096-0A0A
Professional Attachment Set	40233411

	J-150QVP
Standard Presser Foot	A9836-D25-0A0
Hinged Zipper Foot	A9842-D25-0A0
Invisible Zipper Foot (Metal)	A9841-D25-AA0
Smooth Foot	A9840-D25-0A0
Regular Hinged Foot (1/4")	40171426
Regular Hinged Foot (7mm)	40171430
1/4" Presser Foot	40171428
7mm Presser Foot	40171432
Compensating Foot (Right 1/4")	A5149-E98-ZA0
Compensating Foot (Right 7mm)	A9850-D25-0A0
Quilting Foot	40125767
Echo Quilting Foot	40166739
Professional Attachment Set	40233411

	TAJIMA SAI
Pocket Frame	TJPOCKETFRAME
Magnetic Frame	M-FRAME
Sock & Wristband Frame	TJSOCKFRAME
Mounting Base with Sock Gauge	TJGAUGESET
TFA Frame	TFA-9, TFA-15, TFA-18
Shoe Frame	TJSHOEFRAME



	J-350QVP	TL-2200QVP
Quilting Foot	40125767	
Open Toe Foot	40144744	
Invisible Zipper Foot (Metal)	40184899	
Smooth Foot	40201924	

	MO-2000 QVP	MO-1000	MO-735	MO-114D / MO-104D	MO-655	MO-654DE / MO-644D	MO-623	MCS-1500	MCS-1700 QVP
Standard Presser Foot	40134861		A1501-130-0B0	A1501-800-0A0	A1501655B0A	A15016340B0	A15016130BA0	4012001	
Blind Stitch Presser Foot	40138091				A9810-634-0A0A			-	
Universal Blind Stitch Presser Foot	40149058				A9521-634-0A0A			40131946	
Elasticator Presser Foot	40138095				A9815-655-0A0A			-	
Cording Presser Foot	40138099				A9820-655-0A0A			-	
Beading Presser Foot	40138106				A9870-634-0A0A			-	
Curved Beading Presser Foot	40149059				A9511-634-0A0A			-	
Piping Presser Foot	40138103				A9865-655-0A0A			-	
Gathering Presser Foot	40138121				A9860-655-0A0C			-	
Chain Stitch Presser Foot				-				40177370	
Coverstitch Hem Guide	-		40122229		-			40177371	
MO Attachment Set 8pcs	40149062				40123395			-	
MO Attachment Set 6pcs	40149061				40064938			-	
MO Attachment Set 3pcs	40149060				40064939			-	





NOTES

Handwriting practice area with 20 sets of horizontal lines. Each set consists of a solid blue top line, a dashed blue middle line, and a solid grey bottom line.

NOTES

Handwriting practice area with 20 sets of horizontal lines. Each set consists of a solid blue top line, a dashed blue middle line, and a solid grey bottom line.



JUKI CORPORATION

2-11-1, TSURUMAKI, TAMA-SHI, TOKYO
206-8551, JAPAN
<http://www.juki.co.jp>

JUKI AMERICA, INC.

8500 N.W. 17th STREET, SUITE 100
MIAMI, FL 33126-1008, U.S.A.
TEL: 1-305-594-0059 FAX: 1-305-594-0720
<http://www.juki.com>
E-mail: home@juki.com