


PARTS LIST




HZL-35Z

JUKI


«Remarks»

Please order it in an article unnumber on the occasion of part order.

MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			1			43390	40050726	THRUST WASHER
						61227	40050753	M6 PHILLIPS SCREW
						64203	40050766	TAPPING SCREW
						66124	40050776	RUBBER FOOT
						66725	40050781	M4 SCREW
						67533	40050787	RUBBER CUSHION
						72807	40050801	M4 STUD SCREW
						73299	40050808	M4 TORQUE NUT
						76015	40050858	LEG
						76105	40050890	BUSH
						76106	40050891	BUSH
						76429	40050984	EXTENSION TABLE
						76444	40050993	BOTTOM COVER
						76445	40050994	LEG COVER
						76446	40050995	ACCESSORY BOX
						77042	40051066	M4 PHILLIPS SCREW



MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			2			8400	40050711	E5 CLIP-ON-WASHER
						10963	40050712	E6 CLIP-ON-WASHER
						40091	40050724	THRUST WASHER
						43930	40050730	SPRING PIN
						56807	40050739	TIMING BELT
						66787	40050744	THRUST WASHER
						66235	40050777	SECURING PLATE
						66437	40050778	BUSH
						66474	40050779	M5 SCREW
						67447	40050786	M5 SCREW
						73371	40050810	M6 SCREW
						73434	40050811	E4 PHILLIPS SCREW
						75046	40050827	BELT PULLEY
						75047	40050828	CLUTCH
						75060	40050830	TAKE-UP LEVER CRANK
						75072	40050833	BALL BUSHING
						75139	40050837	WASHER
						75158	40050838	COLLAR
						75179	40050841	M5 SCREW
						75182	40050842	COLLAR
						75194	40050845	TORSION SPRING
						75207	40050847	CS-CLIP
						76135	40050905	BELT PULLEY
						76165	40050917	BALANCER
						76182	40050921	TAKE-UP LEVER
						76184	40050923	MAIN SHAFT
						76366	40050977	CRANK SHAFT
						76494	40051011	HAND WHELL
						76688	40051061	SHAFT
						77035	40051064	E4 PHILLIPS SCREW
						77042	40051066	E4 PHILLIPS SCREW
						77070	40051070	SPIRAL GEAR
						85138	40051090	TENSION ROLLER
						88040	40051128	TENSIONING PULLEY BASE



MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			3			1504	40050706	E7 CLIP-ON-WASHER
						6702	40050710	NEEDLE
						8400	40050711	E5 CLIP-ON-WASHER
						26934	40050715	#8 SCREW
						27925	40050716	E2.5 CLIP-ON-WASHER
						28917	40050718	#8 SCREW
						32316	40050719	WASHER
						37515	40050721	WASHER
						42359	40050725	CRINKLE WASHER
						44894	40050731	WASHER
						58220	40050742	WASHER
						61224	40050751	M4 PHILLIPS SCREW
						62215	40050760	M4 NUT
						64359	40050767	M4 SCREW
						66005	40050774	M2 PHILLIPS SCREW
						66481	40050780	M4 STUD SCREW
						66725	40050781	M4 SCREW
						68332	40050788	EXTENSION SPRING
						68343	40050789	PIN
						68380	40050790	M4 STUD SCREW
						72791	40050800	M4 SCREW
						72836	40050804	EXTENSION SPRING
						73299	40050808	M4 TORQUE NUT
						74050	40050815	EXTENSION SPRING
						75024	40050823	STOPPER
						75025	40050824	GUIDE BLOCK
						75027	40050825	COMPRESSION SPRING
						75130	40050835	RATCHET A
						75131	40050836	RATCHET B
						75163	40050839	M4 STUD SCREW
						75196	40050846	TORSION SPRING
						76163	40050916	THREADER SHAFT SET
						76167	40050918	DARNING CONTROL PLATE
						76183	40050922	NEEDLE BAR
						76198	40050928	SCREW WITH SHAFT
						76237	40050942	BOBBIN WINDER COMPLETE
						76543	40051022	SUPPORT BRACKET
						76560	40051034	DARNING SUPPORT PLATE
						76561	40051035	UPPER SUPPORT PLATE
						76562	40051036	SHAFT
						76563	40051037	TORSION SPRING
						76564	40051038	EXTENSION SPRING
						76565	40051039	LOWER SUPPORT PLATE
						76566	40051040	SUPPORT RING
						76567	40051041	PIN
						76568	40051042	LOWER THREAD GUIDE
						76605	40051052	M3 SCREW
						76611	40051053	STOPPER
						77042	40051066	M4 PHILLIPS SCREW
						77043	40051067	FELT
						77053	40051068	M3 PHILLIPS SCREW
						77421	40051071	THREADER ASSEMBLY
						80003	40051080	NEEDLE CLAMP SET
						80073	40051082	NEEDLE BAR CRANK SET
						86046	40081095	THREAD GUIDE


MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			4			1513	40050707	E4 CLIP-ON-WASHER
						32316	40050719	WASHER
						51077	40052009	NEEDLE PLATE SET
						56858	40050740	M2 SCREW
						58741	40050745	CORD GUARD
						61222	40050750	M4 PHILLIPS SCREW
						64051	40050765	M4 SCREW
						64686	40050772	M4 HEX HEADED STUD SCREW
						66725	40050781	M4 SCREW
						66727	40050782	M4 SCREW
						72326	40050799	WASHER
						75191	40050844	COMPRESSION SPRING
						76114	40050896	COVER GUIDE (R)
						76158	40050913	RELEASE LEVER
						76159	40050914	COMPRESSION SPRING
						76169	40050919	STRAIGHT PIN
						76193	40050926	M4 STUD SCREW
						76340	40050966	PRESSER BAR BLOCK
						76432	40050985	PRESSER CONTROL DIAL
						76547	40051024	THREAD CONTROL PLATE
						76571	40051044	PRESSER BAR GUIDE SECURING PLATE
						76572	40051045	PRESSER BAR GUIDE PLATE
						76595	40051051	M8 SCREW
						79491	40051079	M3 SCREW
						80065	40051081	#7 SCREW FOR SHANK
						86256	40051100	COVER GUIDE (L)
						87340	40051101	NEEDLE COVER PLATE
						88026	40051120	PRESSER BAR
						88032	40051123	NEEDLE PLATE
						88039	40055299	FINGER GUARD
						88043	40051130	PRESSER FOOT HOLDER
						88044	40051131	ZIGZAG PRESSER FOOT

MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			5			1513	40050707	E4 CLIP-ON-WASHER
						28917	40050718	HOOK FOR SPRING
						43392	40050727	THRUST WASHER
						51082	40055300	THREAD GUIDE PLATE UNIT
						72266	40050798	M4 STUD SCREW
						74291	40050816	SPRING
						76084	40050883	STRAIGHT PIN
						76276	40050951	AUTO-TENSION PLATE B
						76277	40050952	STUD SCREW
						76278	40050953	STUD SCREW
						76326	40050965	PROTECTION PLATE
						76345	40050968	TENSION RELEASE LEVER B
						76389	40050979	SPRING
						76443	40050992	PRESSURE BAR LIFTER
						76523	40051014	AUTO-TENSION PLATE A
						76573	40051046	TENSION RELEASE LEVER A
						76617	40051055	TORSION SPRING
						77042	40051066	M4 PHILLIPS SCREW
						88023	40051118	REVERSE STITCH LEVER

Exploded view diagram of the sewing machine foot assembly. The diagram shows various components labeled with part numbers and names in Japanese. Key parts include:


- 72266 M4段付ネジ
- 43392 平座金
- 74291 引巻線バネ
- 76523 連動腕A
- 76278 ネジ
- 76276 連動腕B
- 76277 軸ネジ
- 28917 バネ
- 76389 バネ
- 76084 $\phi 5$ ストレート軸
- 76617 ねじりバネ
- 77042 M4ネジ
- 76326 固定片
- 88023 バックレバー
- 1513 E-4
- 51082 DT台(組)
- 76443 押え上げ
- 76573 DT作動板A
- 76345 DT作動板B
- 76276 連動腕B

MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			6			1513	40050707	E4 CLIP-ON-WASHER
						2206	40050709	WASHER
						25436	40050713	E2 CLIP-ON-WASHER
						59221	40050747	WASHER
						61221	40050749	M4 PHILLIPS SCREW
						66725	40050781	M4 SCREW
						76040	40050870	BH CONNECTING ROD A
						76041	40050871	BH SLIDE PLATE A
						76045	40050874	BH SECURING PLATE
						76049	40050875	BH CHANGEOVER LEVER
						76071	40050881	TORSION SPRING
						76358	40050974	NOTCH SPRING
						76364	40050976	PLATE SPRING
						76389	40050979	SPRING
						76456	40051000	BH LEVER CAP
						76492	40051010	HOOK FOR SPRING
						76528	40051017	BH CHANGE LEVER B
						76569	40051043	BH SECURING PLATE
						76644	40051057	BH FUNCTIONING PLATE
						77042	40051066	M4 PHILLIPS SCREW




MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			8			10963	40050712	E6 CLIP—ON—WASHER
						37515	40050721	WASHER
						39817	40050723	M4 PHILLIPS SCREW
						43658	40050728	THRUST WASHER
						43858	40050729	WASHER
						61343	40050755	M4 SCREW
						61381	40050756	CRINKLE WASHER
						64653	40050771	M3 SCREW
						66052	40050775	M4 SCREW
						66481	40050780	M4 STUD SCREW
						66725	40050781	M4 SCREW
						67445	40050785	COLLAR
						67447	40050786	M5 SCREW
						68891	40050792	WASHER
						72791	40050800	M4 SCREW
						72821	40050802	COLLAR
						72826	40050803	EXTENSION SPRING
						73299	40050808	M4 TORQUE NUT
						76025	40051722	FEED DOG BASE
						76026	40050861	FEED REGULATING BRACKET
						76109	40050892	FEED REGULATING LINK R.
						76110	40050893	FEED REGULATING LINK L.
						76111	40050894	HEADED PIN
						76112	40050895	PIN
						76121	40050898	FEED REGULATING ARM.
						76122	40050899	FEED BASE ADJUSTMENT
						76125	40050900	SPRING HOOK PLATE
						76131	40050901	HORIZONTAL FEED SHAFT
						76132	40050902	SHAFT
						76133	40050903	FEED REGULATING SHAFT
						76197	40050927	HEADED PIN
						76199	40050929	PIN
						76206	40050934	TORSION SPRING
						76215	40050937	SPRING
						76324	40050964	M4 SCREW
						76576	40051049	FEED CONTROL LINK
						77035	40051064	M4 PHILLIPS SCREW
						77042	40051066	M4 PHILLIPS SCREW
						77056	40051069	WASHER
						88031	40051721	FEED DOGS

MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			9			1513	40050707	E4 CLIP-ON-WASHER
						8400	40050711	E5 CLIP-ON-WASHER
						28735	40050717	CRINKLE WASHER
						32316	40050719	WASHER
						32949	40050720	WASHER
						53321	40050736	THRUST WASHER
						59221	40050747	WASHER
						61222	40050750	M4 PHILLIPS SCREW
						66725	40050781	M4 PHILLIPS SCREW
						73299	40050808	M4 TORQUE NUT
						73304	40050809	M4 SCREW
						73458	40050813	M4 STUD SCREW
						75169	40050840	HEADED PIN
						76076	40050882	PIN
						76087	40050885	R CONNECTING ROD C
						76351	40050969	BH FINE TUNING PLATE
						76354	40050970	FEED CONTROL LINK A
						76355	40050971	FEED CONTROL LINK B
						76356	40050972	TORSION SPRING
						76363	40050975	BH WIRE ROD
						76462	40051003	ECCENTRIC CAM
						76529	40051018	R FUNCTION PLATE
						76530	40051019	CONNECTING ROD A
						76531	40051020	R. LINK PLATE
						76532	40051021	R CONNECTING ROD B
						76574	40051047	BH CONTROL PLATE SET
						76575	40051048	BH TUNING SETTING PLATE
						76577	40051050	FEED CONTROL ARM




MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			10			1513	40050707	E4 CLIP-ON-WASHER
						32949	40050720	WASHER
						61221	40050749	M4 PHILLIPS SCREW
						66725	40050781	M4 SCREW
						66727	40050782	M4 SCREW
						73299	40050808	M4 TORQUE NUT
						75207	40050847	CS-CLIP
						76029	40050863	PINION SHAFT
						76069	40050879	SECURING SHAFT PLATE
						76282	40050954	S. S. CHANGING LINK ASSEMBLY
						76344	40050967	STITCH LENGTH CONTROL CAM
						76357	40050973	LEAF SPRING
						76439	40050989	STITCH LENGTH CONTROL
						76453	40050999	DIAL INDICATOR
						77042	40051066	M4 PHILLIPS SCREW
						88078	40055301	SEAL

MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			11			1513	40050707	E4 CLIP-ON-WASHER
						8400	40050711	E5 CLIP-ON-WASHER
						25436	40050713	E2 CLIP-ON-WASHER
						39163	40050722	TAPPING SCREW
						53321	40050736	WASHER
						67447	40050786	M5 SCREW
						76052	40050876	SHAFT
						76085	40050884	SPRING
						76096	40050887	ROLLER
						76097	40050888	INDICATOR DRIVER PULLEY
						76150	40050911	BEVEL GEAR
						76228	40050940	STRING (TETRON)
						76235	40050941	STRAIGHT PIN
						76294	40050955	INDICATOR GUIDE PLATE
						76298	40050956	PIN
						76371	40050978	INDICATOR GUIDE PLATE
						76438	40050988	PATTERN SELECTING DIAL
						77042	40051066	M4 PHILLIPS SCREW
						88005	40051106	INDICATOR BRACKET
						88006	40051107	INDICATOR




MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			12			1424	40050705	WASHER
						10963	40050712	E6 CLIP-ON-WASHER
						43390	40050726	THRUST WASHER
						55894	40050738	TAPPING SCREW
						58269	40050743	SPRING PIN
						61225	40050752	M4 PHILLIPS SCREW
						61588	40050757	WASHER
						66235	40050777	SECURING PLATE
						66725	40050781	M4 SCREW
						67444	40050784	COLLAR
						67447	40050786	M5 SCREW
						73434	40050811	M4 PHILLIPS SCREW
						75042	40050826	STRETCH STITCH CAM
						75217	40050848	WORM GEAR
						76028	40050862	BH NOTCH
						76033	40050864	PATTERN CAM
						76034	40050865	CAM SHAFT
						76035	40050866	PINION
						76036	40050867	BH WIDTH CAM
						76038	40050869	BH RING PLATE
						76042	40050872	BH CAP
						76044	40050873	COMPRESSION SPRING
						76055	40050877	RING STOPPER
						76141	40050910	BALL METAL
						76151	40050912	PATTERN SELECTING CAM
						76161	40050915	BH CAM
						76222	40050938	SPRING
						76321	40050963	BRACKET
						77042	40051066	M4 PHILLIPS SCREW
						77435	40051072	LEAF SPRING

MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			13			1424	40050705	WASHER
						1513	40050707	E4 CLIP-ON-WASHER
						1520	40050708	E3 CLIP-ON-WASHER
						10963	40050712	E6 CLIP-ON-WASHER
						32949	40050720	WASHER
						61221	40050749	M4 PHILLIPS SCREW
						61341	40050754	M4 SCREW
						67268	40050783	ECCENTRIC PIN
						73299	40050808	M4 TORQUE NUT
						76324	40050964	M4 SCREW
						76551	40051026	TORSION SPRING
						76552	40051027	ZZ LEVER SECURING PLATE
						76554	40051028	ZZ ADJUSTING PLATE
						76555	40051029	ZZ SECURING PLATER
						76556	40051030	ZZ CONTROL ARM
						76558	40051032	EXTENSION SPRING
						76559	40051033	TORSION SPRING
						76646	40051058	ZIGZAG GUIDE BAR ASSEMBLY(type-B)
						76647	40051059	ZZ CONTROL BLOCK(TYPE-B)
						76648	40051060	ZZ CONTROL CRANK(TYPE-B)
						77042	40051066	M4 PHILLIPS SCREW
						88013	40051113	ZZ LEVER A
						88014	40051114	ZZ LEVER B
						88015	40051115	ZZ LEVER BASE
						88016	40051116	ZZ LEVER COVER
						88017	40051117	ZZ CONTROL PLATE



MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			14			1513	40050707	E4 CLIP-ON-WASHER
						1520	40050708	E3 CLIP-ON-WASHER
						10963	40050712	E6 CLIP-ON-WASHER
						39163	40050722	TAPPING SCREW
						61225	40050752	M4 PHILLIP SCREW
						68922	40050793	M4 SCREW
						72858	40050805	WASHER
						73299	40050808	M4 TORQUE NUT
						73304	40050809	M4 SCREW
						75057	40050829	ZIG ZAG GUIDE BLOCK
						75064	40050832	PATTERN SELECTING CAM CLAW
						75101	40050834	S,STITCH CAM FOLLOWER
						75189	40050843	EXTENSION SPRING
						76058	40050878	STRAIGHT SHAFT
						76070	40050880	GUIDE SHAFT A
						76091	40050886	TORSION SPRING
						76100	40050889	GUIDE SHAFT B
						76223	40050939	PATTERN REGULATING PLATE
						76263	40050949	BH FEED REGULATING PLATE
						76264	40050950	BH FEED PLATE
						76406	40050982	LIMITING PLATE
						76557	40051031	GUIDE PLATE
						77035	40051064	M4 PHILLIP SCREW




MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			15-1			44498	40055302	M3 NUT
						47181	40050732	TAPPING SCREW
						58741	40050745	CORD GUARD
						68891	40050792	WASHER
						72936	40055303	LIGHT BULB
						72938	40055304	HARNESS
						72940	40055305	VINYL TUBE
						72964	40055306	TERMINAL BLOCK COVER
						72966	40055307	SWITCH ASSEMBLY
						72973	40055308	TERMINAL BLOCK
						74889	40055309	MOTOR
						74973	40055310	M4 PHILLIPS SCREW
						75061	40050831	MOTOR PULLEY
						75078	40055311	MOTOR PULLEY FLANGE
						76037	40050868	MOTOR BELT
						76186	40050924	LAMP BASE PLATE
						76473	40051004	BUSH
						76481	40055312	TERMINAL COVER
						76482	40051006	WASHER
						76483	40051007	INSULATION SHEET
						76486	40055313	PIN
						77041	40051065	UNITY FASTENER
						77042	40051066	M4 PHILLIPS SCREW

120V

The diagram illustrates the exploded view of the HZL-35Z(120V) lamp assembly. Components are labeled as follows:

- 72940 チューブ (Tube)
- 77041 ファスナー (Fastener)
- 76481 ターミナルカバー (Terminal Cover)
- 77042 M4バインドネジ (M4 Binding Screw)
- 72966 パワースイッチ (Power Switch)
- 58741 コード押え (Cord Holder)
- 72938 ランプコード (Lamp Cord)
- 76186 ランプ固定板 (Lamp Base Plate)
- 77042 M4バインドネジ (M4 Binding Screw)
- 72964 ターミナルカバー (Terminal Cover)
- 72973 ターミナルブロック (Terminal Block)
- 44498 M3六角ネジ (M3 Hex Nut)
- 68891 平座金 (Flat Washer)
- 75061 モータープーリー (Motor Pulley)
- 75078 リング (Ring)
- 74889 モーター (Motor)
- 76482 樹脂ワッシャ (Resin Washer)
- 76483 絶縁片 (Insulation Sheet)
- 76473 プッシュ (Pusher)
- 76037 タイミングベルト (Timing Belt)
- 72936 電球 (Light Bulb)
- 47181 3.0タツピン (3.0 Pin)
- 74973 M3ネジ (M3 Screw)

MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			16			25670	40050714	WASHER
						47181	40050732	TAPPING SCREW
						54350	40050737	SEAL
						56858	40050740	M2 PHILLIPS SCREW
						61225	40050752	M4 PHILLIPS SCREW
						64203	40050766	TAPPING SCREW
						64360	40050768	TOOTHED WASHER
						64617	40050769	TAPPING SCREW
						73208	40050807	M4 PHILLIPS SCREW
						76192	40050925	REFLECTING SHEET
						76202	40050931	SPOOL PIN
						76242	40050943	BLADE
						76244	40050944	TORSION SPRING
						76317	40050962	M3 PHILLIPS SCREW
						76391	40050980	SEAL
						76423	40050983	SPOOL STAND
						76434	40050986	BED COVER
						76435	40050987	BOTTOM COVER
						76440	40050990	BOBBIN WINDER LATCH
						76447	40050996	ARM CAP
						76448	40050997	DROP KNOB
						76452	40050998	BLADE FIXTURE
						76511	40051012	SEAL
						77042	40051066	M4 PHILLIPS SCREW
						85170	40051091	SPOOL PIN
						85273	40051092	WASHER
						88072	40051134	TRANSPARENT COVER
						88073	40051135	PATTERN PANEL
						88076	40055323	FRONT COVER
						88077	40055324	FACE COVER



MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			17			1520	40050708	E3 CLIP-ON-WASHER
						61224	40050751	M4 PHILLIPS SCREW
						61225	40050752	M4 PHILLIPS SCREW
						63942	40050764	M4 SQUARE NUT
						64957	40050773	TAPPING SCREW
						72791	40050800	M4 SCREW
						73451	40050812	THREAD GUIDE
						76021	40050860	HANDLE STUD
						76395	40050981	TAPPING SCREW
						76442	40050991	HANDLE
						76458	40051001	BUTTONHOLE SEAL
						76459	40051002	BH FINE TUNING DIAL
						77042	40051066	M4 PHILLIPS SCREW
						88003	40051104	BACK COVER
						88046	40051132	THREAD GUIDE PLATE

Exploded view diagram of the HZL-35Z device. The diagram shows the main body, handle, and various fasteners. Key components labeled include:

- 76395 M4タッピングネジ (M4 Tapping Screw)
- 64957 4.0タッピングネジ (4.0 Tapping Screw)
- 77042 M4ハイトネジ (M4 High Screw)
- 61224 M4ハイトネジ (M4 High Screw)
- 88046 糸案内(小) (Thread Guide (Small))
- 63942 四角板ナット (Square Plate Nut)
- 73451 糸案内(組) (Thread Guide (Assembly))
- 76458 BH調整ソール (BH Adjustment Soler)
- 77042 M4ハイトネジ (M4 High Screw)
- 76442 ハンドル (Handle)
- 1520 E-3 (E3 Clip-on Washer)
- 76021 ハンドル軸 (Handle Axis)
- 72791 M4平子 (M4 Flat Head)
- 76459 BH微調ダイヤル (BH Fine Tuning Dial)
- 88003 背面カバー (Back Cover)

MODEL	HZL-35Z(120V)	HZL-35Z(230V)	PAGE			NO	PARTS NO.	DESCRIPTION
			18			51072	40050735	MACHINE COVER
						61711	40050758	PLASTIC BAG
						61725	40050759	NEEDLE SET
						63398	40050761	SEWING MACHINE OIL
						71537	40055325	CARTON
						71538	40055326	SEAL
						72959	40055327	FOOT CONTROL (120V)
						72962	40055328	FOOT CONTROL (230V)
						74765	40050817	SPOOL PIN CAP
						74774	40055329	F.C.BOX
						74793	40050818	SMALL SCREW DRIVER
						75748	40050854	SCREW DRIVER
						76252	40050946	ZIPPER FOOT
						76255	40050947	BLIND STITCH FOOT
						76258	40050948	OVERCASTTING FOOT
						76301	40050957	STYROFOAM PACKING (RIGHT)
						76302	40050958	STYROFOAM PACKING (LEFT)
						76303	40050959	STYROFOAM PACKING (BOTTOM)
						76304	40050960	STYROFOAM PACKING (TOP CENTER)
						76305	40050961	STYROFOAM PACKING (NEEDLE BAR)
						76625	40051056	BOTTONHOLE FOOT
						79070	40051078	SPOOL PIN CAP
						80125	40051083	STYROFOAM PACKING
						80126	40051084	STYROFOAM PACKING
						82015	40053206	INSTRUCCTION BOOK (Eng,Spa,Rus)
						82016	40053207	INSTRUCCTION BOOK (Spa,Fre,Italy)
						85128	A9834-030-0A0	BOBBIN
						85365	40051094	SEAM RIPPER/BRUSH

61725 針セット(#14)
 85128 ボビン
 74765 糸駒キャップ(大)
 79070 糸駒キャップ(小)
 74793 ドライバー小
 51072 ハードカバー
 76304 梱包スチロール(天中央部)
 76302 梱包スチロール(左部)
 76301 梱包スチロール(右部)
 80125 梱包スチロール
 80126 梱包スチロール
 76305 梱包スチロール(針棒部)
 76303 梱包スチロール(底部)
 71537 化粧カートン
 71538(UL) バーコードシール
 76625 BH押え
 63398 オイル
 85365 プラシ付シームリッパー
 75748 針板用ドライバー
 76255 隠し縫い押え
 76252 ファスナー押え
 76258 端縫い押え
 72959 (120V)
 72962 (230V)
 フットコントローラー
 74774
 82015 (英・西・露)
 82016 (西・仏・伊)
 説明書
 61711 ビニール袋

(Optional parts)

NO	PARTS NO.	DESCRIPTION
76545	40052011	WIDE TABLE
77087	40052012	EVEN FEED FOOT
77079	40052013	QUILTING FOOT
	A9133-700-0AA	INVISIBLE ZIPPER FOOT
	A9201-01S-0A0A	SMOOTH FOOT
	A9104-01E-ZA0	ROLLED HEMMING FOOT
	A9190-008-0A0	MANUAL BH PRESSER FOOT
	000421504-000	STRAIGHT STITCH PRESSER FOOT

JUKI CORPORATION

HOUSEHOLD SEWING MACHINE DIV.

8-2-1, KOKURYO-CHO,

CHOFU-SHI, TOKYO 182-8655

JAPAN

PHONE : 03 (3480) 5034

FAX : 03 (3480) 5037

40054742

Copyright © 2006 JUKI CORP.

All rights reserved throughout the world.

06.09 Printed in japan