

A PACKING_TABLE_ASSY

①	TOP_TABLE	×1
②	BOTTOM_TABLE	×1
③	TABLE_SUPPORT_RODS_A	×2
④	TABLE_SUPPORT_RODS_B	×2
⑤	ANTI-DROP_FENCE	×1
⑥	REINFORCING_PLATE	×1
⑦	SCREW (M6×L30)	×6

B PACKING_FOOT_CONTROLLER_ETC.

①	FOOT_CONTROLLER	×1
②	FRONT_RUBBER_SEAT	×1
③	REAR_RUBBER_SEAT	×2
④	SCREW (M6×L100)	×12
⑤	WASHER (M6)	×18
⑥	SCREW (M6×L30)	×2
⑦	SCREW (M6×L16)	×4
⑧	SCREW (M8×L20)	×10
⑨	WASHER (M8)	×10
⑩	SPRING_WASHER (M8)	×10

ENGLISH

Congratulations on your purchase of a JUKI product.

Please read this Setup Manual carefully before using the table in order to get the most of it and to enjoy using it for a long time. It is recommended to keep this Setup Manual to read it whenever necessary.

⚠ Caution: Be sure to read this Setup Manual before assembling and using your quilting table.

1. Be sure to secure a place for unpacking the quilting table. Place a rag or the like before unpacking to protect the floor and existing furniture from being damaged.
2. Be sure to assemble the quilting table with two or more persons.
3. Carry out assembly while carefully preventing accidents such that fingers are caught in the product, a heavy thing drops on onto feet, etc.
4. Be sure to secure a sufficient space when moving and installing the main body of sewing machine. If not, unexpected accidents and physical damages to goods can occur.
5. Avoid the use of the product in such a place that is exposed to the direct sunlight or hot air from a heater, or that is in hot and humid conditions, since the use in any of such places can cause deformation, discoloring or deterioration of the product.

⚠ Warning: Be sure to read this Setup Manual before assembling and using your quilting table.

1. When moving the quilting table, be sure to remove first the main body of the sewing machine from the quilting table. Then, hold both ends of the bottom table with two or more persons. If it is inevitable to carry the table with the main body of sewing machine placed on it, be sure to remove the power cord of the main body of sewing machine and carefully carry the table taking care not to drop the sewing machine from the table.
2. Do not use the quilting table for any other purpose than its intended use such as for standing on it or for placing a heavy thing on it.
3. Do not bounce on the quilting table. Doing so can break the table resulting in personal injury.
4. Do not place a thing which has high moisture content on the quilting table. Using such a thing can deform or deteriorate the table.

I . Assembling the quilting table (Fig. 1)

1. Remove anti-drop fence (A-⑤) and reinforcing plate (A-⑥) which is fixed to the top table (A-①). Reinforcing plate (A-⑥) and screws (A-⑦) that was removed will not be used.
2. Fix top table (A-①), bottom table (A-②), table support rods A (A-③) (two pieces) and table support rods B (A-④) (two pieces) with screws (M6 x L100) (B-④) and washers (M6) (B-⑤) (12 pieces each) as illustrated in the figure.
3. Since the accessory screws supplied with the stand have sharp sections on its periphery, use screws (M8 x L20) (B-⑧), washers (M8) (B-⑨) and spring washers (M8) (B-⑩) (10 pieces each).
4. Fix the table on the stand with screws (M6 x L16) (B-⑦) and washers (M6) (B-⑤) (four pieces each).

II . Attaching rubber vibration isolators (Fig. 2)

1. Remove the plate (C in the figure) from the front of the undersurface of the main body of sewing machine. Turn the plate by 180 degrees as illustrated in Fig. 2-1 and fix it on the illustrated location of the undersurface of main body of sewing machine.
2. Wipe dirt and smear off the plate on the front side of undersurface (C in the figure) and off the plate on the rear side of undersurface (D in the figure) with alcohol or the like. If alcohol is not available, wipe the plates with a soft cloth moistened with diluted neutral detergent, then with a soft cloth moistened with water and dry well.
3. Attach front rubber seat (B-②) (one piece) and rear rubber seats (B-③) (two pieces) on the illustrated locations with double-sided adhesive tape.

III . Setting up the main body of sewing machine (Fig. 3)

1. Insert the main body of sewing machine into U-shaped notch in top table (A-①) from the direction of arrow E. At this time a uniform clearance should be maintained between the U-shaped notch and the periphery of the main body of sewing machine.
2. Insert the plug of foot controller (B-①) into a predetermined position of the stitch regulator. Refer to the Instruction Manual for the main body of sewing machine and that for the stitch regulator.
3. After the completion of installation of the main body of sewing machine, fix anti-drop fence (A-⑤) on top table (A-①) with screws (M6 x L30) (B-⑥) and washers (M6) (B-⑤) (two pieces each).

40155845

Si prega di leggere questo Manuale di installazione prima di utilizzare il tavolo al fine di ottenere il meglio dal prodotto. Congratulazioni per l'acquisto di un prodotto JUKI.

Nuestro agradecimiento y felicitaciones por su compra de este producto JUKI. Tenga a bien leer el presente Manual de instalación y preparación detenidamente antes de usar la mesa, para que

ITALIANO

ESPAÑOL